

Agilent 4339B High Resistance Meter User's Guide

Manual Change

Agilent Part No. NA

August 2008

Change 1

Replace step a. in "5. Perform the Open Correction" in 3-7 with the following sentences.

- a. Turn the load knob counterclockwise (CCW) until the distance between the upper electrode and the lower electrode is about 10mm.

Note: If turning the load knob counterclockwise until the upper electrode does not move, there is a risk that the cover is not close-fitting enough.



Agilent Technologies

マニュアル チェンジ

Agilent Part No. NA

August 2008

チェンジ 1

ページ **3-7** 内、“**5.** オープン補正を実行します。”の次、ステップ **a** を以下の文章に変更してください。

- a.** 上の電極と下の電極の距離が約 **10mm** になるまで、ロード・ノブを左に回します。

注記：上の電極が動かなくなるまで、ロード・ノブを回すとテスト・フィクスチャのカバーが閉まらなくなる可能性があります。



Agilent 4339B High Resistance Meter
User's Guide



Agilent Technologies

Agilent Part No. 04339-90041
Printed in JAPAN January 2001

Fifth Edition

Notice

The information contained in this document is subject to change without notice.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of the Agilent Technologies.

Agilent Technologies Japan, Ltd.
Component Test PGU-Kobe
1-3-2, Murotani, Nishi-ku, Kobe-shi,
Hyogo, 651-2241 Japan

Manual Printing History

March 1996	First Edition (part number: 04339-90021)
December 1996	Second Edition (part number: 04339-90031)
July 1999	Third Edition (part number: 04339-90041)
March 2000	Fourth Edition (part number: 04339-90041)
January 2001	Fifth Edition (part number: 04339-90041)

Safety Summary

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific **WARNINGS** elsewhere in this manual may impair the protection provided by the equipment. In addition it violates safety standards of design, manufacture, and intended use of the instrument.

The Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.

Note



4339B is designed for use in INSTALLATION CATEGORY II according to IEC 61010-1 and POLLUTION DEGREE 1 according to IEC 61010-1 and IEC 60664-1. 4339B is an INDOOR USE product.

Note



LEDs in 4339B are Class 1 in accordance with IEC60825-1.
CLASS 1 LED PRODUCT

Ground The Instrument

To avoid electric shock hazard, the instrument chassis and cabinet must be connected to a safety earth ground by the supplied power cable with earth blade.

DO NOT Operate In An Explosive Atmosphere

Do not operate the instrument in the presence of flammable gasses or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

Keep Away From Live Circuits

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

DO NOT Service Or Adjust Alone

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT Substitute Parts Or Modify Instrument

Because of the danger of introducing additional hazards, do not install substitute parts or perform unauthorized modifications to the instrument. Return the instrument to a Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained.

Dangerous Procedure Warnings

Warnings , such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

Warning



Dangerous voltages, capable of causing death, are present in this instrument. Use extreme caution when handling, testing, and adjusting this instrument.

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility, or to the calibration facilities of other International Standards Organization members.

Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period of one year from the date of shipment, except that in the case of certain components listed in *General Information* of this manual, the warranty shall be for the specified period. During the warranty period, Agilent Technologies will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instruction when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

Limitation Of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

No other warranty is expressed or implied. Agilent Technologies specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

Exclusive Remedies

The remedies provided herein are buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales and Service Office. Addresses are provided at the back of this manual.

Safety Symbols

General definitions of safety symbols used on equipment or in manuals are listed below.



Instruction manual symbol: the product is marked with this symbol when it is necessary for the user to refer to the instruction manual.



Alternating current.



Direct current.



On (Supply).



Off (Supply).

Warning



This **Warning** sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death to personnel.

Caution



This **Caution** sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.

Note



Note denotes important information. It calls attention to a procedure, practice, condition or the like, which is essential to highlight.




Affixed to product containing static sensitive devices use anti-static handling procedures to prevent electrostatic discharge damage to component.



Caution, risk of electric shock : Terminals which may be supplied from the interior of the equipment at a voltage exceeding 1 kV, or allow connection to a voltage exceeding 1 kV are marked with this symbol.


4339B

4339B High Resistance Meter at a Glance.



indicates the voltage output exceeds 42 V.


(In this book, the BLUE shift key is expressed as )

Warning  **Do not touch the UNKNOWN terminals or the electrodes of the accessory, when the High Voltage indicator is ON.**



Annunciator ( symbols, at the bottom of the display)

Shows the instrument's operational state. For example,



Indicates the measurement sequence single mode is selected.

Indicates that internal trigger is selected.

LA100003

In User's Guide

■ Chapter 1, Preparation for Use

For initial turn on of the 4339B

■ Chapter 2, Operating the 4339B

Basic measurement operation

Getting acquainted with the 4339B—for beginners

Handy reference for common measurement tasks—for all users

■ Chapter 3, Measurement Examples

Measurement Examples for typical 4339B applications

Measuring Insulation Resistance of a Capacitor

Measuring Volume Resistivity of a Insulation Material

In the User's Guide, information on the following subjects is not discussed:

- | | |
|-----------------------|------------------|
| • Initial Inspection | • Maintenance |
| • GPIB remote control | • Specifications |
| • Using with Handler | • Error Messages |




For detailed information on these subjects, see the *4339B Operation Manual*.




Contents

1. Preparation for Use


In This Chapter	1-1
Power Requirements	1-1
To Set Power LINE Voltage	1-1
To Set Power LINE Frequency	1-2

2. Operating the 4339B

In This Chapter	2-1
To Reset 4339B to its Default Settings	2-2
 To Connect Test Fixture	2-2
16008B Resistivity Cell	2-2
16117B Low Noise Test Lead	2-3
16339A Component Test Fixture	2-3
To Perform Calibration—Canceling internal measurement errors	2-4
To Set Test Voltage	2-4
To Set Current Limit	2-4
 To Perform OPEN Correction	
—Canceling the stray admittance in parallel with the DUT	2-5
If “Out Of Limit” is displayed	2-5
 To Connect DUT	2-6
To Select Measurement Parameter	2-6
Setting the Parameters for Resistivity Measurement	2-7
Setting Thickness of the DUT	2-7
Setting the Electrode Size	2-7
To Select Measurement Range	2-8
Auto Range mode—Automatically selecting the optimum measurement range	2-8
Hold Range mode—Holding the measurement range of your choice	2-8
To Select Measurement Time Mode	2-8
To Set Averaging Rate—Stabilizing the measurement result	2-9
To Select Trigger Mode	2-9
To Set Trigger Delay Time	2-9
To Use Deviation Measurement Function	2-10
Setting the Deviation Reference Values	2-10
Selecting the Deviation Mode	2-10
To Use Comparator Function	2-11
Setting the Limit Values	2-11
Sorting	2-11
To Select Display Mode	2-12
To Select Beeper Mode	2-13
To Use Contact Check Function —Monitoring the connection of test electrodes and DUT	2-13
To Print Measurement Data	2-14
Setting the Printer	2-14

Printing	2-14
Disabling Printing	2-14
To Use Measurement Sequence Function	
—Controlling charge-measurement in a sequence	2-15
Selecting the Measurement Sequence Mode	2-15
Setting the Measurement Sequence	2-15
 Starting Measurement Sequence	2-16
Aborting Measurement Sequence	2-16
 To Apply Test Voltage	2-16
To Trigger a Measurement	2-16
 To Turn OFF Voltage Output	2-16
Reference	2-17
Default Settings	2-17
Accessories Available	2-17
Test Fixtures and Test Leads	2-17
16064B LED Display/Trigger Box	2-19
Other Topics	2-20
If You Have a Problem	2-20

3. Measurement Examples

 In This Chapter	3-1
Measuring Insulation Resistance of Capacitor	3-2
Measurement Setup	3-2
Measurement Procedure	3-2
For More Information	3-5
Measuring Resistivity of Insulation Material	3-6
Measurement Setup	3-6
Measurement Procedure	3-6
For More Information	3-9

Figures

2-1. Printer Output	2-14
-------------------------------	------

Tables

1-1. Power Voltage Selector Setting	1-1
---	-----

Preparation for Use

In This Chapter

Before turning the 4339B ON, you must first set the 4339B to match the available power LINE voltage.

If the 4339B's power LINE voltage and frequency are properly set and ready to use, you can skip this chapter.

Power Requirements

The 4339B's power source requirements are as follows:

LINE Voltage : 100 / 120 / 220 / 240 V ac ($\pm 10\%$)



LINE Frequency : 47 to 66 Hz

Power Consumption : 45 VA maximum


To Set Power LINE Voltage

1. Confirm that the power cable is disconnected.
2. Slide the LINE Voltage selector on the rear panel to match the power LINE voltage which will be used (see Table 1-1).

Table 1-1. Power Voltage Selector Setting

Voltage Selector	Line Voltage	Required Fuse
	100V/120Vac($\pm 10\%$)	UL/CSA type, Time delay 0.5A 250V (Agilent part number 2110-0202)
	220V/240Vac($\pm 10\%$)	UL/CSA type, Time delay 0.25A 250V (Agilent part number 2110-0201)

4339B Rear Panel



To Set Power LINE Frequency

1. Connect the power cable to the power cord receptacle on the rear panel.
2. Push the LINE switch in. The 4339B will emit a beep and perform the self test. (If any message is displayed, see “Error Messages” back of *4339B Operation Manual*.) The 4339B will be ready for operation after a message like the following is displayed.



HP 4339B Rev. xx.xx
Dec. 13 1995

LA001005

3. Press  . The following menu is displayed.



R: +0.0000 Ω Vout: 0.000 V
Offset Beep Exit more Clmt: 500.0 μ A

LA001034

4. Press  until more blinks, and press .

R: +0.0000 Ω Vout: 0.000 V
Line Svc Test Exit more Clmt: 500.0 μ A




LA001134

5. Press  until Line blinks, and press .

R: +0.0000 Ω Vout: 0.000 V
LINE FREQ: 50Hz 60Hz Clmt: 500.0 μ A

LA001116

A blinking item means that it is currently selected.

6. If the setting does not match the power LINE frequency, press  to toggle the setting between 50Hz and 60Hz, then press .
7. Select Exit and press  to exit this menu.

Note





The power line frequency setting is stored and is not changed after reset or power-off. Once you set it, you do not need to set the line frequency again as long as the same power line frequency is being used.


Operating the 4339B



In This Chapter

Basic measurement operations of the 4339B and references are explained.

To Reset 4339B to its Default Settings

1. Press   to select the reset menu.





2. Press  until Yes blinks, and press .

For more information about the default settings, see “Default Settings” later in this chapter.


To Connect Test Fixture

Connect the test fixture to the UNKNOWN terminals as follows:

Warning  Do not touch the UNKNOWN terminals or the electrodes of the accessory, when the High Voltage indicator is ON, the 4339B outputs dangerous voltage of up to 1000 Vdc. Before handling the 4339B or the accessory, turn OFF the test voltage pressing  and confirm that the High Voltage indicator is OFF.

16008B Resistivity Cell

The 16008B is used to measure the volume or surface resistance/resistivity of insulation materials.




Three size electrodes are available. For detail see “Accessories Available” later in this chapter.


2-2 Operating the 4339B

16117B Low Noise Test Lead

The 16117B is used to measure the resistance of insulation materials.




For floating DUT measurement




For grounded DUT measurement

16339A Component Test Fixture


The 16339A is used to measure insulation resistance of electronic components.




Top view (cover is opened)
of the HP 16339A




To set the component module :




Pull the clamps up.



Insert the module.



Push the clamps down.



connect the banana cables.

Three type modules are available. For detail see “Accessories Available” later in this chapter.

* Measuring a high capacitance DUT keeping good S/N ratio, change the short bar to an appropriate resistor. For detail, see page 3-6 of *16339A Component Test Fixture Operation and Service Manual*.

To Perform Calibration—Canceling internal measurement errors

1. Press  .


LA001008

R: +0.0000 Ω	Vout: 0.000 V
ExecCal Exit	Clmt: 500.0 μ A

2. Select ExecCal using  or  and press . The 4339B will perform the calibration.





After the calibration is completed with the message Calibration Complete, the 4339B will return to the measurement display.

To Set Test Voltage

1. Press . The voltage setting menu will be displayed.

LA001016

R: +0.0000 Ω	Vout: 0.000 V
Voltage [V] = 0.0	Clmt: 500.0 μ A


2. Enter the value using the numeric ENTRY keys (for example, to set 100 V, press   , then press .

To Set Current Limit

1. Press  .

LA002022


R: +0.0000 Ω	Vout: 100.0 V
Current Limit [mA] = 0.5	Clmt: 500.0 μ A


2. Enter the current limit value using the numeric keys, then press  to enter the value and to exit.


Available current limits are:



0.5 mA (default)	5.0 mA (at test voltage 0 to 250 V only)
1.0 mA	10 mA (at test voltage 0 to 100 V only)
2.0 mA (at test voltage 0 to 500 V only)	


⚠ To Perform OPEN Correction —Canceling the stray admittance in parallel with the DUT




1. Separate each electrode of the test fixture. For details about fixture operation, refer to “Test Fixtures and Test Leads” later in this chapter.
2. Press . A source voltage is applied to the test fixture, and the **V Output** indicator will turn ON.




Warning ⚠ Pressing  may cause the 4339B to output dangerous voltage, up to 1000 Vdc. Do *not* touch the UNKNOWN terminals or the electrodes of the accessory when the V Output indicator is ON.

3. Press  . The OPEN correction menu will be displayed.



4. Select **OpenMeas** using  or  and press . The 4339B will perform the OPEN correction.

After a while, the 4339B will display the message **Correction Complete**, and return to the measurement mode.

5. Press  to turn the voltage OFF. The **V Output** indicator will turn OFF.

If “Out Of Limit” is displayed



The OPEN admittance is so high that it would be unsuitable for OPEN correction data.

- Check that the test electrodes are properly opened.

Perform the OPEN correction again.

To Connect DUT

Set the DUT to the test fixture. For details, see “Test Fixtures and Test Leads”.




Warning  Do *not* touch the UNKNOWN terminals or the electrodes of the accessory, when the High Voltage indicator is ON, the 4339B outputs dangerous voltage of up to 1000 Vdc. Before handling the 4339B or the accessory, turn OFF the test voltage pressing  and confirm that the High Voltage indicator is OFF.


To Select Measurement Parameter

- Press . The measurement parameter selection menu will be displayed.

LA001128

R:	+0.0000	Ω		Vout:	100.0 V
R	I	Rs	Rv	Clmt:	500.0 μ A

- Select the desired parameter using  or  and press . (R:Resistance, I:Current, Rv:Volume resistivity ρ_v , Rs:Surface resistivity ρ_s)

Note  If the 16008B resistivity cell is connected to the 4339B, to change volume and surface resistivity, switch the volume/surface selector on the resistivity cell.

Setting the Parameters for Resistivity Measurement

If you measure the volume or surface resistivity, set the parameters as follows:

Press   .

LA002006


R: +0.0000 Ω	Vout: 0.000 V
Thickness Rescell Exit	Clmt: 500.0 μ A

Setting Thickness of the DUT

1. Select Thickness using  or  and press  .

LA002007

R: +0.0000 Ω	Vout: 0.000 V
Thickness [mm] = 2.0000	Clmt: 500.0 μ A

2. Enter the thickness value using the numeric ENTRY keys, and press  .

LA002008




R: +0.0000 Ω	Vout: 0.000 V
Thickness Rescell Exit	Clmt: 500.0 μ A

Setting the Electrode Size

1. Select ResCell using  or  and press  .

LA002008

R: +0.0000 Ω	Vout: 0.000 V
26 50 76 User Exit	Clmt: 500.0 μ A

2. Select the electrode size that you want to use (26mm, 50mm, or 76mm) using  or  , and press  .


LA002009

R: +0.0000 Ω	Vout: 0.000 V
D: 50mm - 70mm B = 0.0000	Clmt: 500.0 μ A

3. Press  .

LA002006

R: +0.0000 Ω	Vout: 0.000 V
Thickness Rescell Exit	Clmt: 500.0 μ A

4. Select Exit and press  to exit the menu.

To Select Measurement Range

Auto Range mode


—Automatically selecting the optimum measurement range




Press . The **Hold Range** annunciator(▼) turns OFF.

Hold Range mode—Holding the measurement range of your choice

To select the measurement range,

1. Press . The measurement range setup menu is displayed.




2. Press  or  until the desired range is displayed. Or, input the current value to be measured using the numeric ENTRY keys, and the 4339B will select the optimum measurement range setting.
3. Press . The **Hold Range** annunciator(▼) turns ON.

Available measurement ranges:

100 pA (Not available at measurement time Short)
 1 nA
 10 nA
 100 nA
 1 μ A
 10 μ A
 100 μ A (Available at measurement time Short only)





To Select Measurement Time Mode

Press  until the **Meas Time** annunciator(▼) points to the desired measurement time mode : **Short**, **Med**(Medium) or **Long**.


To Set Averaging Rate—Stabilizing the measurement result

1. Press  .




2. Enter the averaging rate using the numeric ENTRY keys. (For example, to enter 4, press .) You can enter integer values from 1 to 256. Also, you can increase or decrease the value using  or .
3. Press  to set the value and to exit.

To Select Trigger Mode

Press  until the **Trigger** annunciator(▼) points to the desired trigger mode.

Int(Internal) Free running measurement


Man(Manual) Triggers a measurement when  is pressed.





Ext(External) Triggers a measurement by external trigger signal input (through the external trigger connector or handler interface).

To trigger a measurement in each mode, see “To Trigger a Measurement” later in this chapter.

To Set Trigger Delay Time

1. Press  .



2. Enter the desired trigger delay time using the numeric ENTRY keys. (For example, to set 0.5 s, press   .) You can set the trigger delay time from 0 s to 9.999 s.
3. Press  to set the value and to exit.

To Use Deviation Measurement Function

Setting the Deviation Reference Values

1. Press  .

LA002116


R: +0.0000	Ω	Vout: 100.0 V
ModeSet	Δ RefEnt	Clmt: 500.0 μ A
Exit		

2. Select Δ RefEnt using  or  and press .

LA002016

R: +0.0000	Ω	Vout: 100.0 V
Δ Reference = +0.0000		Clmt: 500.0 μ A

3. Enter the numeric value using the numeric ENTRY keys.




4. Press  to enter the value.

Selecting the Deviation Mode

5. Select ModeSet using  or  and press .

LA002117

R: +0.0000	Ω	Vout: 100.0 V
Off	Δ ABS Δ %	Clmt: 500.0 μ A

6. Select the desired mode using  or  and press .

Δ ABS mode: Measured value–Reference

LA002017

Δ R: +0.0000	Ω	Vout: 100.0 V
		Clmt: 500.0 μ A


Δ % mode: (Measured value–Reference)/Reference \times 100 %

LA002028

Δ R: +9.9E+37 %		Vout: 100.0 V
		Clmt: 500.0 μ A


To Use Comparator Function


Setting the Limit Values

1. Press .

LA002014


R: +0.0000 Ω Low Limit = -9.9000E+37	Vout: 100.0 V Clmt: 500.0 μ A
--	--------------------------------------

2. Enter the lower limit value using the numeric ENTRY keys, then press  to enter the value. You can set the value from -9.900×10^{37} to 9.900×10^{37} .

3. Press .

LA002114

R: +0.0000 Ω High Limit = +9.9000E+37	Vout: 100.0 V Clmt: 500.0 μ A
---	--------------------------------------

4. Enter the upper limit value using the numeric ENTRY keys, then press  to enter the value and to exit. You can set the value from -9.900×10^{37} to 9.900×10^{37} .

Sorting

To start sorting,

Press  . The **Comprtr On** annunciator(▼) turns ON.

To turn sorting OFF,

Press   again. The **Comprtr On** annunciator turns OFF.

The sorting results are HIGH, IN, and LOW.

Where,


HIGH	greater than higher limit
IN	between higher limit and lower limit
LOW	less than lower limit

The 4339B shows the comparison results using the display, beeper, printer, and 16064B LED Display/Trigger Box. (To use the 16064B, see “Accessories Available” later in this chapter.)

- For result output to the display, see “To Select Display Mode” in the next page.
- For result output to the beeper, see “To Select Beeper Mode” in the next page.
- For result output to the printer, see “To Print Measurement Data” later in this chapter.

To Select Display Mode


Press   .





Select the desired mode using  or  and press  .

(Data:Measurement Display, Comprtr:Comparison Display, Off:Display OFF)

If you select **Format**, the following menu will be displayed. You can select the display digits and display format of the Measurement Display mode.




To select the display digits, select **Digit** and press  . Then select the display digits from 3, 4 or 5.

To select the display format for the measurement data, select **R-Unit** and press  . Then select **Exponent** mode or **Prefix** mode.


Each display mode shows the result as follows:

- The Measurement Display mode shows the measurement data:

Exponent mode



Prefix mode



- The Comparison Display mode shows the comparison results:




- The Display OFF mode (DISP OFF) does not show any measurement result.


To Select Beeper Mode




To change the beeper mode for the comparator result reporting:

1. Press  .






2. Select Beep using  or  and press  to select.



3. Select the beep mode using  or , and press  to exit to the previous display.


OFF	No beep
FAIL	Emits a beep when the comparator result is HIGH, LOW, or the contact check FAILED.
PASS	Emits a beep when the comparator result is IN.




4. Select Exit using  or , and press  to exit.


To Use Contact Check Function —Monitoring the connection of test electrodes and DUT




To enable or disable the contact check function:


1. Press  .



2. Select ON/OFF using  or  and press  to select.



3. Select On or Off using  or , and press  to exit to the previous display.

4. Select Exit using  or , and press  to exit.

5. The **Cont Chk** annunciator(▼) turns ON if the contact check function is on.

When contact check failed, the 4339B displays N.C.(No-Contact). The limit value for the contact check function is changable. Refer to *Operation Manual*.

The OPEN correction function must be performed correctly for a valid contact check.

To Print Measurement Data


Setting the Printer


1. Use an GPIB compatible printer, set to the listen-always mode.
2. Connect the printer to the 4339B's GPIB port on the rear panel.
3. Turn the printer ON.

Printing

Set the 4339B to talk only mode (Set the 4339B's GPIB address to 31).

1. Press     .



2. Press  . The **Talk Only** annunciator(▼) turns ON, and the printer begins printing the measurement data.




Figure 2-1. Printer Output

Disabling Printing

Change the GPIB address to an address other than 31 (for example, 17, which is the default setting).

- Press      .

To Use Measurement Sequence Function —Controlling charge-measurement in a sequence

Selecting the Measurement Sequence Mode

Press  .



LA002118

R: +0.0000 Ω	Vout: 100.0 V
Off Single Continuous	Clmt: 500.0 μ A

Select the desired mode using  or  and press  .

Single Single mode
Continuous Continuous mode
Off Measurement sequence OFF (normal measurement mode)

Setting the Measurement Sequence

1. Press   . The sequence mode menu will be displayed.

LA002018


R: +0.0000 Ω	Vout: 100.0 V
Chrg Intvl TimeDisp Exit	Clmt: 500.0 μ A

2. Set Charge time.

- a. Select Chrg using  or  and press  .

LA002019

R: +0.0000 Ω	Vout: 100.0 V
Charge Time [s] = 10.00	Clmt: 500.0 μ A


- b. Enter the charge time using the numeric ENTRY keys, and press  .

3. Set Interval time and Number of repetitions (**Cont** mode only).

- a. Select Intvl using  or  and press  .


LA002020


R: +0.0000 Ω	Vout: 100.0 V
Interval Time [s] = 1.000	Clmt: 500.0 μ A

- b. Enter the interval time using the numeric ENTRY keys, and press  .

LA002021



R: +0.0000 Ω	Vout: 100.0 V
Memory Size = 500	Clmt: 500.0 μ A

- c. Enter the number of measurement points (equivalent to Memory size), and press  .

4. Select Exit and press  to exit.

Starting Measurement Sequence


Press . The **Seq Running** annunciator() turns ON.


Warning  Pressing  may cause the 4339B to output dangerous voltage, up to 1000 Vdc. Do *not* touch the UNKNOWN terminals or the electrodes of the accessory, when the V output indicator is ON.



Aborting Measurement Sequence

Press  . The **Seq Running** annunciator() turns OFF.


To Apply Test Voltage

Press . The **V Output** indicator turns ON.





Warning  Pressing  may output dangerous voltage, up to 1000 Vdc. Do *not* touch the UNKNOWN terminals or the electrodes of the accessory when the V Output indicator is ON.

To Trigger a Measurement

- In internal trigger mode—The 4339B makes continuous free-running measurements.
- In manual trigger mode—Press  when you want to trigger a measurement.
- In external trigger mode— Connect the external trigger source to the EXT TRIGGER terminal on the 4339B's rear panel, and apply a TTL level trigger signal to trigger a measurement. (For details, see the *4339B Operation Manual*.)
Note that the 4339B must be set to the external trigger mode to be triggered from an external handler or from the 16064B LED Display/Trigger Box.

To Turn OFF Voltage Output

Press  and confirm the **V Output** indicator and the **High Voltage** indicator is turn OFF.

Warning  If the High Voltage Indicator turns ON after turning OFF the test voltage, the DUT is still charged. This happens especially for capacitive DUTs. Do *NOT* handle the DUT while the High Voltage Indicator is turned ON. When the charge on the DUT discharges to a safe level(less than 42 V) the High Voltage indicator will turn OFF.

Reference


Default Settings

- Test voltage output : OFF
- Test voltage : 0 V
- Current limit : 0.5 mA
- Measurement parameter : R
- Resistivity cell
 - D1 : 50 mm
 - D2 : 70 mm
 - t : 2 mm
 - B : 0
- Deviation measurement : OFF
- Measurement range : Auto
- Measurement time : MEdium
- Averaging rate : 1
- Trigger mode : Internal
- Trigger delay time : 0 ms
- Comparator : OFF
- Contact check : OFF
- Display mode : Measurement mode
- Beep mode : FAIL mode
- Offset-error canceling : OFF
- OPEN correction data is cleared


Accessories Available

Test Fixtures and Test Leads

Following test fixtures and test leads are available for the 4339B for various forms of DUTs.



16008B



For an OPEN correction


Turn the load knob counterclockwise until the upper electrode does not move.

Connecting the DUT


Turn the load knob clockwise until the load scale indicates between 0 kg and 10 kg.

16339A


SMD module



Axial Lead module




Alligator clip and Flat table



For an OPEN correction


same as the DUT's width




Tighten the screw to hold the electrode.

Nothing must be connected to electrode.


Remove the alligator clips.



16117B




Floating DUT measurement



For grounded DUT measurement

4339B



16118A



16064B LED Display/Trigger Box

The 16064B LED Display/Trigger Box triggers a measurement when its trigger key is pressed, and displays the comparison results using LEDs. It allows you to manually operate the comparator function of the 4339B.

4339B
High Resistance Meter



16064B
LED Display/Trigger Box



**Connect to the Handler Interface connector
on the rear panel.**

Other Topics

For details on these functions, see the *4339B Operation Manual*.

- Initial Inspection — Chapter 1 of the *Operation Manual*
- Auto-Offset Canceling — Chapter 2 and Chapter 3 of the *Operation Manual*
- Key Lock Function — Chapter 2 and Chapter 3 of the *Operation Manual*
- GPIB — Chapter 4 and Chapter 5 of the *Operation Manual*
- Handler Interface — Chapter 3 and Appendix B of the *Operation Manual*
- Save / Recall — Chapter 2 and Chapter 3 of the *Operation Manual*
- Backup Function — Chapter 3 of the *Operation Manual*
- Specification — Chapter 8 of the *Operation Manual*
- Maintenance — Chapter 9 of the *Operation Manual*
- Error Messages — “Error Messages” in back of the *Operation Manual*




If You Have a Problem

If any of the problems listed below occur, follow the instructions given for the problem.

- If you find yourself lost when operating the 4339B



You can get back on track by:

To return to the measurement mode Press  several times. When Exit is in the menu, select it and press .


To return to the default settings Press  . Select Yes and press . If the reset is not accepted, confirm that the **Key Lock** annunciator(▼) is turned ON. See next.

- If the 4339B does not accept key input:

- Check whether or not the **Key Lock** annunciator(▼) is ON. If so:

- Press  . The **Key Lock** annunciator(▼) turns OFF and the front-panel keys are unlocked.

- Check that the 16064B LED display/trigger box is connected to the 4339B and it is set to lock out the keys. If so, unlock the keys from the 16064B.

- If  is not accepted:

- Check whether the interlock connector is firmly connected.
- If you are using the 16008B or the 16339A,
 - Check whether the top cover of the test fixture is closed.




- If ----- or “OVLD” is displayed:

The measurement result is out of the measurable range. Check the DUT and make sure the measurement range is properly set.

Measurement Examples

In This Chapter

The 4339B's features are discussed, which you can investigate by trying the typical measurement examples described in this chapter.

Warning   Do *not* touch the UNKNOWN terminals or the electrodes of the accessory, when the High Voltage indicator is ON, the 4339B outputs dangerous voltage of up to 1000 Vdc. Before handling the 4339B or the accessory, turn OFF the test voltage pressing  and confirm that the High Voltage indicator is OFF.

Measuring Insulation Resistance of Capacitor

This example shows the procedure to measure insulation resistance of capacitor after charged 1 minute. Using the test sequence measurement function reduces the measurement complexity.

DUT

Chip ceramic capacitor

Requirements

Test Fixture : 16339A, SMD module

Measurement Setup

Measurement Parameter : R

Measurement Range : Auto range mode


Test Voltage : 100 V

Use the measurement sequence single mode (measure after charged for 1 minute.)

Measurement Procedure


1. Reset the 4339B.

a. Press  .




b. Select Yes using  or  and press .

2. Connect the test fixture to the UNKNOWN terminals as follows:



To set the SMD module :



Pull the clamps up.

Insert the SMD module.

Push the clamps down.

Connect the banana cables.

* For detail, see “16339A Component Test Fixture” in Chapter 2.

3. Perform calibration.

Press  .

LA001008

R: +0.0000 Ω ExecCal Exit	Vout: 0.000 V Clmt: 500.0 μ A
--	--------------------------------------





Select ExecCal using  or  and press . After a while, the calibration will be completed with the message “Calibration Complete”.

4. Set the test voltage.

- a. Press .


LA001016

R: +0.0000 Ω Voltage [V] = 0.0	Vout: 0.000 V Clmt: 500.0 μ A
--	--------------------------------------

- b. Press      to set the test voltage to 100 V.

5. Perform the OPEN correction.

- a. Separate the test electrodes and fix them (nothing must be connected to the electrodes).







- b. Close the cover.

- c. Press .

LA001128

R: +0.0000 Ω R I Rs Rv	Vout: 100.0 V Clmt: 500.0 μ A
---	--------------------------------------


- d. Select I using  or  and press  to select the current measurement mode displayed.

- e. Press . The **Meas Time** annunciator(▼) will indicate **Long**.

- f. Press  to turn ON the test voltage.

The **V Output** indicator will turn ON.

- g. Wait until the I value has stabilized within 0.5 pA.





- h. Press   .

LA103010


I: +0.12 pA	Vout: 100.0 V
OpenMeas MeasVal Exit	Clmt: 500.0 μ A

- i. Select OpenMeas using  or  and press  .

After a while, the OPEN correction will be completed with the message “Correction Complete”. (If Out Of Limit is displayed, see “ To Perform OPEN Correction –Canceling the stray admittance in parallel with the DUT” in Chapter 2.)

- j. Press  to turn OFF the test voltage. The **V Output** indicator will turn OFF.




6. Connect the DUT and close the cover.



7. Press  .

LA103128

I: +0.12 pA	Vout: 100.0 V
R I Rs Rv	Clmt: 500.0 μ A

8. Select R using  or  and press  to select the resistance measurement mode. R(Resistance).

9. Set the measurement sequence charging time to 1 minute.

- a. Press   .

LA002018


R: +0.0000 Ω	Vout: 100.0 V
Chrg Intvl TimeDisp Exit	Clmt: 500.0 μ A

- b. Select Chrg using  or  and press  .

LA002019

R: +0.0000 Ω	Vout: 100.0 V
Charge Time [s] = 10.00	Clmt: 500.0 μ A

- c. Press    .


- d. Select Exit and press  to exit.


4339B

e. Press  .



f. Select Single using  or  and press .

10. Press  . After charging 1 minute, the measurement result will be displayed. The following figure shows the typical measurement result display.



For More Information

- To print out the measurement result — See “To Print Measurement Data” in Chapter 2
- To select measurement level — See “To Set Test Voltage” in Chapter 2

Measuring Resistivity of Insulation Material

This example shows the procedure to measure resistivity of an insulation material after charged 1 minute. The 16008B Resistivity Cell is a right tool to measure resistivity of solid insulation materials.

DUT

Insulation Material
(5 mm × 120 mm × 120 mm)

Requirements

Test Fixture : 16008B, ϕ 50 mm electrode

Measurement Setup

Measurement parameter : $R_v(\rho v)$

Measurement Range : Auto range mode


Test Voltage : 500 V



Use the measurement sequence single mode (measure after charged for 1 minute.)

Measurement Procedure


- Reset the 4339B.

- Press   .



- Select Yes using  or  and press  .

- Connect the test fixture to the UNKNOWN terminals as follows:



4339B

3. Perform calibration.

- a. Press  .

LA001008

R: +0.0000 Ω	Vout: 0.000 V
ExecCal Exit	Clmt: 500.0 μ A

- b. Select ExecCal using  or  and press .

After a while, the calibration is completed with the message "Calibration Complete".

4. Set the test voltage.

- a. Press .


LA001016

R: +0.0000 Ω	Vout: 0.000 V
Voltage [V] = 0.0	Clmt: 500.0 μ A

- b. Press     to set the test voltage to 500 V.

5. Perform the OPEN correction.

- a. Turn the load knob counterclockwise(ccw) until the upper electrode does not move.













- b. Close the cover.






- c. Press .


LA103100

R: +0.0000 Ω	Vout: 500.0 V
R I Rv	Clmt: 500.0 μ A

- d. Select I using  or  and press  to select the current measurement mode.
- e. Press . The **Meas Time** annunciator() will indicate **Long**.
- f. Press . The **V Output** indicator will turn ON.
- g. Wait until the I value has stabilized within 0.5 pA.
- h. Press  .







- i. Select OpenMeas using  or  and press .
- After a while, the OPEN correction is completed with the message “Correction Complete”. (If Out Of Limit is displayed, see “ To Perform OPEN Correction—Canceling the stray admittance in parallel with the DUT” in Chapter 2.)
- j. Press . The **V Output** indicator will turn OFF.
6. Set the DUT.
- a. Place the DUT on the Main electrode.



- b. Turn the load knob and stick the electrode on the DUT. (Let the load scale indicate more than 0 kg and less than 10 kg.)
- c. Close the cover.
7. Set the measurement parameter to Rv(ρ_v : volume resistivity).
- a. Turn the Volume/Surface selector of the 16008B to “Volume”.

- b. Press .



- c. Select Rv using  or  and press .


4339B

8. Set the measurement sequence charging time to 1 minute.

- a. Press  .

LA103118


Rv: +0.0000	Ω cm	Vout: 500.0 V
Chrg	Intvl	Clmt: 500.0 μ A
TimeDisp	Exit	

- b. Select Chrg and press .

LA103119

Rv: +0.0000	Ω cm	Vout: 500.0 V
Charge Time [s] = 10.00		Clmt: 500.0 μ A

- c. Press   .


- d. Select Exit and press  to exit.

- e. Press .

LA103120

Rv: +0.0000	Ω cm	Vout: 500.0 V
Off	Single	Clmt: 500.0 μ A
Continuous		

- f. Select Single using  or  and press .

9. Press . After charging 1 minute, the measurement result will be displayed. The following figure shows the typical measurement result display.

LA103121

Rv: +8.7159E+13 Ω cm	Vout: 500.0 V
	Clmt: 500.0 μ A

For More Information

- To print out the measurement result — See “To Print Measurement Data” in Chapter 2
- To select other measurement parameters — See “To Select Measurement Parameter” in Chapter 2
- To select measurement level — See “To Set Test Voltage” in Chapter 2

